

Wireless Speaker Interface

Audio Connection

The Wireless Speaker Interface connects to your sound system using the PA Horn Cable provided. Plug the 3.5mm (headphone) plug into the wireless interface and the RCA plug at the other end of the cable into a line input on your sound system. The line input on your amplifier may be labeled “Aux” or “Line” or “Left” or “Right”, etc.

Power Connection

Plug the A/C adapter into the wireless interface to turn it on, unplug the A/C adapter from the unit to turn the wireless interface off. To reduce the chance of the wireless interface losing its settings, ***always plug and unplug power directly at the wireless interface, do not turn it on and off at the A/C outlet.***

Operation

Wherever the speaker or wireless speaker is mentioned in the Dog Agility Timer manual, your sound system with the external wireless interface operates exactly the same. The only difference is in the “Programming the Wireless Speaker” section of the manual. When the manual instructs you to turn the amplified speaker off or on, these on/off instructions apply *only to the wireless interface unit*. Have your sound system already powered on and volume adjusted during the entire procedure.