WARRANTY INFORMATION

ONE YEAR LIMITED WARRANTY:

If within one year from the date of purchase, any part of your A/C Eliminator fails to function properly due to a defect in material or workmanship, FarmTek, Inc. will repair or replace the defective unit free of charge. Purchaser is responsible for costs incurred in the delivery or shipment of the defective unit to FarmTek, Inc. for repair.

FarmTek, Inc. is not responsible for any consequential damages caused by the use or misuse of the A/C Eliminator

Some states do not allow the exclusion or limitation of consequential damages and some states do not allow limitations on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

IF YOUR EQUIPMENT NEEDS REPAIR:

Returns are not accepted without a RETURN AUTHORIZATION NUMBER. This number can be obtained by calling or writing Farm-Tek, Inc. and describing the nature of the problem. All returns must be clearly marked with the return authorization number on the package.

A/C Eliminator

User's Manual

FarmTek /

FarmTek, Inc.

1000-D Hwy 78 North (972) 429-0947 Wylie, TX 75098 (800) 755-6529 **Congratulations on your purchase!** Your new A/C Eliminator should provide years of trouble-free service. To maximize the performance and life of your A/C Eliminator, please read this user's manually before using it at your first event.

INTRODUCTION

The A/C Eliminator is a rechargeable battery pack for the timer console. It allows use of the timer console without A/C power. The A/C Eliminator provides power for up to 20 hours before recharging is necessary, depending on the accessories plugged into the timer console.

USING THE A/C ELIMINATOR

The A/C Eliminator replaces the A/C adapter normally used to power the timer console. The A/C Eliminator will properly operate the timer console when the console is used by itself or when connected to the long range electric eyes used for barrel racing. The A/C Eliminator *will not* properly power the timer console when using the reflector electric eyes (for roping). The A/C Eliminator *will not* operate the Transmitter electric eye.

To operate the timer console using the A/C Eliminator, plug the cable exiting from the Eliminator into the **POWER** jack on the rear of the timer console. The timer is now on – just as if the A/C adapter was plugged in. If the timer does not immediately turn on, unplug the Eliminator and plug it back in.

When used for barrel racing with one pair of electric eyes, the A/C Eliminator will power the timer console for about 20 hours. If two pairs of electric eyes are used (e.g., jumping events, dashes, etc.), the batteries in the A/C Eliminator will last about 15 hours.

CHARGING THE A/C ELIMINATOR

The A/C Eliminator is not charged when shipped. It should be given a full charge, as outlined below, as soon as possible. The A/C Eliminator provides about 15 to 20 hours of use before recharging is necessary. Typically, this is enough time to use the Eliminator on four or five separate occasions before recharging is necessary. In fact, it is actually

<u>better</u> for the batteries to be used for 15 to 20 hours before recharging, rather than just a few hours--as if recharged after each use.

To recharge the A/C Eliminator, insert the plug from either of the A/C adapters provided with your timer into the jack on the Eliminator. Let the unit charge about 14 hours.

STORING THE A/C ELIMINATOR

When not in use, make sure the plug from the A/C eliminator is not touching anything metal. Do not insert the plug into the jack on the A/C eliminator. The batteries will remain almost fully charged for several weeks if stored at room temperature. If stored for a period of two or more months, recharge the batteries overnight before the next use. During long periods of storage, the battery should be given a full charge before putting the unit away, and every three months or so thereafter.

A/C Eliminator User's Manual © 1999 FarmTek, Inc.