

## Storing Agility Pole Bases

The pole bases are stored on a retainer pipe with four spacers and a knob.

Beginning with a **pole base**, slide the base onto the retainer pipe, followed by a spacer. Alternate between pole base and spacer until all bases are on the retainer pipe and the last spacer is positioned on top. Screw on the knob after the last spacer to keep the bases in place.

